



DYNAMIC BALANCE ANALYZER

OPERATING MANUAL

Version 1.2

TABLE OF CONTENTS

| | |
|--------------------------------------|-----------|
| INTRODUCTION | 1 |
| INSTALLATION | 1 |
| OPERATION | 2 |
| TESTING A DISC | 2 |
| SET LIMITS | 2 |
| MODE..... | 3 |
| Display Mode..... | 3 |
| Test Speed | 4 |
| CALIBRATION | 4 |
| Spindle Calibration | 4 |
| Disc Calibration..... | 4 |
| Angle Calibration | 5 |
| USING THE PRINTER..... | 5 |
| USING THE SERIAL INTERFACE | 6 |
| Communications Parameters..... | 6 |
| Message Format..... | 7 |
| Command Codes | 7 |
| CALIBRATION DISCS | 8 |
| MAINTENANCE AND SERVICE | 8 |
| Removing the Dust Cover | 8 |
| Removing the Top Cover | 8 |
| Changing the EPROM..... | 9 |
| SPECIFICATIONS..... | 10 |

INTRODUCTION

The Clover Systems Dynamic Balance Analyzer is a tool for measuring imbalance of DVD and CD discs. Specification of disc imbalance was added to the Red Book standard in 1994. Conformance to Red / Yellow / Orange Book standards can be verified with this system. The Clover Systems Balance Analyzer is a compact and easy-to-use desktop system that measures disc imbalance in accordance to Philips / Sony Red Book and Orange Book standards. It will display the results in either g-mm (gram-millimeters) or Newtons. It will also display PASS or FAIL based on a user-settable limit. It also displays the direction of imbalance in degrees.

The advent of high-speed CD-ROM and DVD-ROM drives makes disc unbalance an important issue. The forces generated increase with the square of the rotational rate, so at high speeds, the forces are extreme. These forces and resultant vibration can adversely affect disc performance and drive life.

High-speed CD-ROM drives will reduce their read speed if they have trouble reading the disc. One of the causes of speed reduction is vibration caused by disc unbalance. Only a properly balanced disc will provide the maximum throughput these drives are capable of.

Disc imbalance can be caused by thickness variation of the substrate, lacquer coating, CD-R dye coating, or DVD bonding layer as well as asymmetrical label design.

If a printer is attached to the built-in printer port, results of each test will be printed.

An RS-232 serial connection is provided on the rear panel for connection to a PC. Optional software provides data collection, display, and archiving of test results.

INSTALLATION

When unpacking, be sure to remove the gray foam under the dust cover that protects the disc spindle. Save the box and packing materials in case you need to ship the unit.

Place the unit on a sturdy, flat surface. Vibration from external sources could affect the results.

Check to make sure that the AC line voltage selector on the rear panel is set to match your local AC power. In the 115v position, the unit will accommodate input voltages from 90 VAC to 130 VAC, 50/60 Hz. In the 230v position, it will work with input voltages from 180 VAC to 260 VAC, 50/60 Hz.

If you are using a printer, connect it to the PRINTER port on the rear panel of the Balance Analyzer using an ordinary PC parallel printer cable. You can use any printer, which has a Centronics type parallel interface and accepts ASCII text.

You can also connect the serial port to a computer using the cable supplied (see SERIAL INTERFACE - Pg. 6).



OPERATION

TESTING A DISC

NOTE -- Allow the unit to "warm up" for 10 minutes before making any measurements.

Open the dust cover by lifting up on the front handle. Place the disc on the spindle by holding the disc by the edge and placing it over the spindle hub. Let it drop down on the hub, then gently press the disc straight down flat against the turntable with your fingers. It makes no difference how the disc is oriented or whether it is right side up. Be sure that it is flat against the turntable. To start the test, press TEST. The disc will spin up to 1800 RPM. Once the disc speed is phase locked to the crystal oscillator, the test will begin. The test takes 8 seconds at the FAST speed, and 13.5 seconds at SLOW speed. When the disc has stopped, the results will be displayed. Results include the disc imbalance in g-mm or Newtons, the angle of the imbalance in degrees, and either "--- PASS ---" or "**** FAIL ****" depending on whether the measured value exceeds the limit set by the user (see SET LIMITS below).

Once the disc has stopped, open the dust cover and remove the disc by lifting the edge of the disc with fingers of both hands. Be sure to lift straight up, so that the spindle hub is not damaged. It may be helpful to press down on the spindle hub with your thumbs while lifting with your fingers.

It is OK to press down on the top of the spindle hub, but you should avoid touching the sides of the inner spindle hub. Grabbing the inner spindle hub (the part with the metal fingers) could deform it and affect the measurements.

It is not necessary to close the dust cover for every test. The main purpose of the dust cover is to exclude strong air currents from HVAC systems, which can affect the results. If air currents are not a problem, you can leave the cover open.

The direction of imbalance is displayed as part of the test result. To locate this direction on the disc, use the protractor printed on the top of the unit: With the disc stopped, turn the disc by hand until the green LED just above the 0° mark on the scale lights. When the LED first lights while turning the disc clockwise, the protractor scale will read correctly.

Please note that if the disc (or spindle) is perfectly balanced, the measured angle of imbalance will be meaningless and random. Similarly, the measured angle of well-balanced discs will have more variation than that of poorly balanced discs.

SET LIMITS

You can set an upper limit for the disc imbalance. If the current measurement exceeds this limit, the display will show "**** FAIL ****" at the end of the test. Otherwise, it will display "---PASS ---". This provides a means of setting up a GO / NO GO test. PASS or FAIL is also printed on the printer for each test.



Press the SET button. The current limit setting will be displayed. You can change it in 0.1 g.mm increments by pressing the up arrow ↑ or down arrow ↓ buttons. Once it is set to the desired limit, press SET again. This will bring you to the angle calibration mode (see CALIBRATION below). Pressing SET again will return you to the normal mode.

Here are the standards for disc unbalance as set by the Philips Red Book, Yellow Book, and Orange Book:

| STANDARD | MAX. Ud (g.mm) | MAX Fu (N) |
|--|-----------------------------|-----------------------------|
| Red Book | $U_d \leq 10 \text{ g.mm}$ | $F_u \leq 0.0395 \text{ N}$ |
| Yellow Book | $U_d \leq 7 \text{ g.mm}^*$ | $F_u \leq 0.0276 \text{ N}$ |
| Orange Book CD-R (12cm) | $U_d < 2.5 \text{ g.mm}$ | $F_u < 0.01 \text{ N}$ |
| All 8cm Discs (incl. CD business card) | $U_d < 1 \text{ g.mm}$ | $F_u < 0.004 \text{ N}$ |
| Orange Book CD-RW | $U_d < 2.5 \text{ g.mm}$ | $F_u < 0.01 \text{ N}$ |
| DVD | $U_d \leq 10 \text{ g.mm}$ | $F_u \leq 0.0395 \text{ N}$ |

Notes: g.mm = Gram Millimeters, N = Newtons.

U_d = Disc Unbalance, F_u = Unbalance Force at 10 Hz rotation rate.

* $U_d \leq 5 \text{ g.mm}$ is recommended.

The reported imbalance force (F_u) is normalized to an equivalent force at a rotation speed of 10 Hz to match the standards.

MODE

The MODE button allows you to select the display units, the test speed, and calibration mode. Repeatedly pressing MODE sequences through these settings.

Display Mode

The results of the test can be displayed in units of either gram-millimeters or Newtons. The mode button allows you to change the display units. First press MODE. The current display units in use are now shown. If you wish to change it, press up arrow ↑ or down arrow ↓ to toggle between gram-millimeters and Newtons. Press MODE again to exit. The display mode is saved in non-volatile memory, so it is retained even with the power off.



Test Speed

There are two test speeds that can be selected: FAST or SLOW. SLOW is the default mode, and should be used whenever possible. The FAST mode allows for a shorter test time, but sacrifices some accuracy.

To change the test speed, press MODE. Current display units are now shown. Press MODE again to show the current speed setting. Use the up arrow ↑ or down arrow ↓ to toggle between speeds. Press MODE again to exit. The test speed is saved in non-volatile memory, so it is retained even with the power off.

CALIBRATION

NOTE -- Allow the unit to "warm up" for 10 minutes before making any measurements or attempting calibration.

There are two calibration modes, which are selected by the MODE button.

Spindle Calibration

Spindle Calibration measures the imbalance of the spindle and motor. This value is then subtracted from the measured disc value. This allows accurate results even if the spindle is not perfectly balanced.

The spindle balance value is stored in non-volatile memory, so it is retained even with the power off. This procedure has been done at the factory, so theoretically there is no need to perform this function unless the spindle has been removed.

To perform the spindle calibration, press CAL. Then press MODE to select spindle calibration. Remove any disc present on the spindle, and press CAL again. At the end of the procedure, the results are displayed for a couple seconds and the unit returns to its normal mode.

Disc Calibration

Disc Calibration allows you to change the sensitivity of the unit to match known calibration standards. Two calibration discs are provided, but you can use any disc with known imbalance.

Before attempting disc calibration, you should first use the system for a while to get a feel for the natural variation in results. Results will naturally vary ± 0.15 g-mm due to the centering accuracy of the disc.

Ordinarily, calibration is not required on a regular basis. Calibration is only required if something in the system has changed. If you are getting unexpected results from a test, you should first check to see if the disc is mounted on the spindle crooked before changing calibration.

To calibrate the unit, place a disc on the spindle and press CAL. Now press CAL again to select Disc Calibration. The disc will spin up and continuously measure until you stop it by pressing CAL again. Let it run for 30 or 60 seconds to get a stable



reading. To change the sensitivity, press up arrow ↑ or down arrow ↓ to increase or decrease the sensitivity. Since each measurement takes several seconds, the value will change only every five or ten seconds (depending on the SPEED). The sensitivity is increased / decreased in very small steps (about 0.05 g.mm) when ↑ or ↓ are pressed, and as long as the buttons are held down. With a little practice you can get a feel for how long to hold down the button. For small adjustments, just press the button two or three times, then wait for the measurement value to be updated.

In order to indicate when the value is updated, a "*" is displayed in the first column of the bottom row on the display. When the "*" appears or disappears, you know the value has been updated.

The measurement sensitivity is saved in non-volatile memory, so it is retained even with the power off. When checking spindle or disc calibration, remember that the TEST result is the important one; CAL results may be slightly different.

NOTE -- The first disc test after performing Disc Calibration may be erroneous and should be ignored.

Angle Calibration

You can adjust the angle measurement ± 30 degrees using the SET mode. Press SET to get to the LIMIT screen. Now press SET again to enter angle calibration mode. The current setting of "phase shift" is displayed. This is an offset added to the angle measurement for calibration purposes. This is set at the factory, and ordinarily should not need to be changed unless some component is changed. To calibrate the angle, use a disc with known angle of imbalance, such as the provided calibration disc. If the measured angle does not correspond to the indicator on the top of the unit (when the green LED is lit), then you can increase or decrease the measured angle by pressing the up arrow ↑ or down arrow ↓ keys. The current offset is displayed, and saved in non-volatile memory.

USING THE PRINTER

The Dynamic Balance Analyzer will work with any printer with parallel (Centronics) interface that prints ASCII text. Please note that some printers will work only with Microsoft Windows and cannot be used. When selecting a printer, make sure that it is "MS-DOS Compatible".

Connect the printer to the Dynamic Balance Analyzer with a PC parallel printer cable (DB-25P to Centronics). Be sure that the printer is turned off or set to "off-line" before connecting or disconnecting it. Enable printing by selecting "ON-LINE" on your printer. If the printer is not ON-LINE, or turned off, the Dynamic Balance Analyzer will simply ignore it.

With the printer connected, turned on, and selected, the printer will print a header when the first disc is tested after turning on power to the Dynamic Balance Analyzer.



The printer will print the results of each test as it is completed. This includes the amount of imbalance in g-mm (or Newtons), the angle of the imbalance in degrees, and "--- PASS ---" or "*** FAIL ***" depending on whether the measured value is greater than the limit set by the user.

USING THE SERIAL INTERFACE

The serial interface is an RS-232 connection on a DB-9 connector. It connects to a PC using an ordinary 9-pin serial cable. The cable should be "straight through" and not a "null modem" cable, as the Balance Analyzer is wired as DCE (Data Communications Equipment).

The Dynamic Balance Analyzer sends ASCII text with comma delimiters and a carriage-return at the end of the record. The easiest way to use the Balance Analyzer with a Windows PC is to run HyperTerminal, which comes with Windows. Set up HyperTerminal to communicate directly to the COM port you wish to use. Set the communications parameters as shown below. You can control the DBA by typing the commands shown below, and the results will be displayed on the screen, and can be saved. It is also possible to direct the DBA results into a spreadsheet.

Communications Parameters

9600 baud, 8 data bits, one stop bit, no parity, no flow control.



Message Format

The message consists of four items separated by commas, with a carriage-return + linefeed at the end:

"PASS" (or "FAIL"),

Measurement result (g.mm or Newtons, depending on mode setting),

Current Limit Setting (g.mm or Newtons, depending on mode setting),

Speed ("FAST" or "SLOW", depending on mode setting)

Carriage Return + Linefeed

Here are actual results from Windows HyperTerminal:

```
PASS,9.7 g.mm,10.0 g.mm,SLOW
PASS,9.6 g.mm,10.0 g.mm,SLOW
PASS,9.6 g.mm,10.0 g.mm,SLOW
PASS,2.9 g.mm,10.0 g.mm,SLOW
PASS,2.8 g.mm,10.0 g.mm,CAL
PASS,2.9 g.mm,10.0 g.mm,SLOW
FAIL,10.0 g.mm,10.0 g.mm,SLOW
FAIL,10.1 g.mm,10.0 g.mm,SLOW
FAIL,10.2 g.mm,10.0 g.mm,SLOW
PASS,9.5 g.mm,10.0 g.mm,SLOW
PASS,9.6 g.mm,10.0 g.mm,SLOW
PASS,9.6 g.mm,10.0 g.mm,SLOW
```

Command Codes

The Dynamic Balance Analyzer can also be controlled using the serial interface. All front panel commands can be duplicated by commands sent to the serial port.

| COMMAND | ASCII CODE | ASCII CHARACTER | PC KEYBOARD CODE |
|---------|------------|-----------------|------------------|
| ↑ | 81h (129d) | ü | ALT + 0129 |
| CAL | 82h (130d) | é | ALT + 0130 |
| SET | 84h (132d) | ä | ALT + 0132 |
| ↓ | 98h (152d) | ÿ | ALT + 0152 |
| MODE | 94h (148d) | ö | ALT + 0148 |
| TEST | A4h (164d) | ñ | ALT + 0164 |



CALIBRATION DISCS

Supplied with your unit are two discs with known imbalance. They are calibrated using Philips Standards. Both discs are provided with measured results from your tester before it left the factory. To confirm that your system is operating properly, test both discs and compare the results with the results we have provided. If the results are significantly different, you may need to calibrate the system. Calibration discs are also available directly from Philips at www.licensing.philips.com.

MAINTENANCE AND SERVICE

Ordinarily, there are no adjustments or maintenance required. If you need to replace the fuse for any reason, use a ½ Amp fuse.

If you need repairs, first call us for help in diagnosing the problem, and to get a return authorization and shipping instructions:

Tel: +1 949.499.9566
Fax: +1 949.499.4844
Email: Service@CloverSystems.com
Internet: www.cloversystems.com

Please save the original shipping carton and packing materials in case you need to ship it for any reason. If you are unable to save the original shipping materials, you must wrap the Balance Analyzer in at least 3" of bubble-pak before shipping. Secure the disc spindle with the original foam, or packing tape.

Removing the Dust Cover

In case you wish to remove or replace the dust cover, just open the dust cover and remove the four screws fixing the hinges to the top cover using a Phillips screwdriver. The nuts on the inside are attached to the top cover, so there is no need to remove the top cover.

Removing the Top Cover

WARNING -- Do not exert any force on the motor spindle or shaft, as this may damage the spindle or motor mount.

In order to change the firmware EPROM, you will need to remove the top cover.

1. Unplug the AC power cord from the player.



2. Open the dust cover and remove the spindle: Use the special tool provided to pull the spindle off the motor shaft. DO NOT grasp the inner hub. Deforming the inner hub will affect the performance.
3. Cover the hole in the spindle hub with tape to keep dirt from falling into the hole. Do not place tape over the black index mark, as this may stick to the tape and come off.

WARNING -- Do not allow anything (dirt, dust, etc.) to enter the hole in the spindle, as this will affect the performance.

4. Remove the four Phillips head screws in the top cover near the spindle.
5. Remove the four screws holding the top cover, which are on the sides of the chassis.
6. Slide the top cover towards the rear of the chassis about 3/8" to disengage the lip on the top cover that engages with the front panel.
7. Now lift the top cover up until you can reach inside.
8. Remove the wire to the green LED. It simply pulls off. When re-installing, the red wire goes toward the front of the chassis.
9. Remove the ribbon cables going to the display and keyboard. When re-installing, the keyboard cable is keyed, and can only go one way. The display is marked where pins 1 & 2 are. Pin one is the red wire.
10. The top cover can now be fully removed.

Changing the EPROM

To gain access to the EPROM, remove the three screws holding the top circuit board. Tilt up the top circuit board to get to the EPROM on the lower PCB. If necessary, you can disconnect J1, J2, & J3 by pushing them out of their sockets with a small flatblade screwdriver - do not pull on the wires.

The firmware EPROM is an integrated circuit located on the main circuit board labeled 16-009. This IC is in a socket labeled U4. It should have a label on it with the Clover Systems logo. Remove the chip from the socket using an IC removal tool or small screwdriver. Gently pry the chip from the socket, being sure that you are prying up the chip only, and not the socket.

Installation is simply a matter of pressing the new IC into the socket. One end of the EPROM IC has a notch in it. Align the chip so that the end with the notch is facing the rear of the unit. Make sure all pins go into the holes in the socket, and press the IC into the socket. To re-assemble, follow steps 1-10 in reverse order.



SPECIFICATIONS

- Resolution = 0.1 g-mm (4×10^{-5} Newton)
- Repeatability / Accuracy = ± 0.15 g.mm
- Range = 0.0 - 17.0 g-mm (0 - 0.07 N)
- Rotational speed = 1800 RPM
- Angular accuracy = ± 3 degrees
- AC voltage = 115 / 230 VAC, 50 / 60 Hz, $\frac{1}{2}$ A
- Power consumption = 30 W
- Dimensions = 17" x 13" x 4.75"
- Weight = 20 lbs.

